



## SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

**REV. 00**

[www.cobra.it](http://www.cobra.it)

MAKE **VOLKSWAGEN** MOD. **GOLF 5\*** YEAR **04** → PETROL   
DIESEL

\* Models with original equipment keyless entry system.

<b>ALARM/SIREN POSITION</b>	Position the compact alarms and the sirens on the bracket near the bonnet lock.
<b>CENTRAL UNIT POSITION</b>	Position the modular systems and the modules under the central tunnel or under the passenger's seat.
<b>POWER SUPPLY</b>	<b>+30:</b> connect to one of the general supply in the fuse box. <b>-31:</b> connect with a cable terminal directly to the grounded system behind the driver's side sill cover.
<b>IGNITION WIRE</b>	<b>+15/54:</b> connect to the BLACK wire, at the position nr.11, of the 11 way black connector marked "G", coming out of the central placed on the left of the steering column, under the driver's side dashboard.
<b>DIRECTION INDICATORS</b>	<b>Anterior and posterior direction indicators connection</b> Connect to the wires: BLACK/WHITE (BLACK/GREY) at the position nr. 11 in the 21 way light brown connector marked "D", BLACK/GREEN at the position nr. 10 in the black connector marked "B"; BLACK/WHITE at the position nr. 8 and BLACK/GREEN at the position nr. 6 in the 12 way black connector marked "A". In order to make such connection it is necessary to separate the lines by means of diodes mod. 1N4004.
<b>ACTIVAT./DEACTIVATION CONTROLS</b>	<b>Connection antitheft/vehicle</b> Refer to the <b>fitting diagram nr. 211.</b>
<b>IMMOBILISATION POINT</b>	<b>Gasoil pump</b> Cut the 1 mm <sup>2</sup> BLUE/BLACK wire at the position nr.27 behind the fuse box.
<b>STARTER</b>	<b>+50:</b> Cut the 0,35 mm <sup>2</sup> RED/BLACK wire, at the position nr.1, in the 12 way black connector marked "G", in the central placed under the driver's side dashboard.
<b>BONNET SWITCH</b>	Connect to the BROWN/LIGHT BLUE wire, in the wiring harness coming out of the lamp in the bonnet. Connect to the BROWN/GREEN wire, at the position nr.5, of the connector marked "F" coming out of the central on the left of the steering column.
<b>DOORS SWITCH</b>	Connect to the BROWN/WHITE wire, in the wiring harness behind the lateral bulkhead, driver's side.
<b>BOOT SWITCH</b>	Connect to the BLACK/RED wire, at the position nr.8, located in the wiring harness coming out of the 17 way light brown connector, in the central placed in the posterior part of the boot covering, passenger's side.

**FITTING DIAGRAM NR. 211**

Connection 3800 serie antitheft on **GOLF 5** year 2004

