

54M Wireless Router

54M
Wireless Router
Model No.: TL-WR340G
TL-WR340GD

- Status
- Basic Settings ---
- Quick Setup
- Network
- Wireless
 - Wireless Settings
 - MAC Filtering
 - Wireless Statistics
- Advanced Settings ---
- DHCP
- Forwarding
- Security
- Static Routing
- Dynamic DNS
- Maintenance ---
- System Tools

Wireless Settings

Wireless Setting

Note: The operating wireless connection via physical placement of place your router.

- Near the center of wireless stations
- In an elevated location
- Away from sources of interference, such as cordless phones
- With the Antenna
- Away from large

Note: Failure to follow significant performance wirelessly connect to the

SSID - Enter a value of Name (SSID) must be a in your network. The de strongly recommended name (SSID) to a diffe sensitive. For example, **MySsid**.

Region - Select your This field specifies th function of the router ca use the wireless functio than one of those speci or region is not liste government agency for

Channel - This field frequency will be used. the wireless channel u problems with another r

Mode - Select the desir are:

- 54Mbps (802.11g)** - 802.11b wireless router.
- 11Mbps (802.11b)** - stations can cor

Note: The default is allows both 802.11g ar connect to the router.

Enable Wireless Rout of the router can be wireless stations acce stations will be able to

SSID:

Region:

Warning: Ensure you select a correct country to co Incorrect settings may cause interference

Channel:

Mode:

Enable Wireless Router Radio

Enable SSID Broadcast

Enable Bridges

MAC of AP1:

MAC of AP2:

MAC of AP3:

MAC of AP4:

MAC of AP5:

MAC of AP6:

Enable Wireless Security

Security Type:

Security Option:

WEP Key Format:

Key Selected	WEP Key	Key Type
Key 1: <input type="radio"/>	<input type="text" value="1a2b3"/>	<input type="text" value="64bit"/>
Key 2: <input checked="" type="radio"/>	<input type="text"/>	<input type="text" value="128bit"/>
Key 3: <input type="radio"/>	<input type="text"/>	<input type="text" value="Disabled"/>
Key 4: <input type="radio"/>	<input type="text"/>	<input type="text" value="Disabled"/>