



3.3 KEYBOARD UNIT

A
B
C
D
E
F



PM5005A				PM5007A			
P1	NC	P10	Vdd1	P1	NC	P10	NC
P2	PGND	P11	D1	P2	CVcc	P11	NC
P3	BIAS1CON	P12	D2	P3	CKC	P12	CKC
P4	AVcc	P13	CKD	P4	LS	P13	LS
P5	BIAS2DOT	P14	LS	P5	Vdd1	P14	Vdd1
P6	IREF1CON	P15	CKA	P6	DGND	P15	DGND
P7	IREF2DOT	P16	AVcc	P7	PGND	P16	PGND
P8	GND	P17	PGND	P8	CVcc	P17	CVcc
P9	Vdd0	P18	NC	P9	NC	P18	NC



A

B

C

D

E

F