




DVD-5002P

Service Manual - DVD-5002P



PART NO.	CAT NO.		QTY	
1	GBIP8.074.032	display top cover	1	
2	GBIP8.038.126	copper pole	4	
3	GBIP6.604.813	11P terminal	1	
4	GBIP2.855.551MX	high-volt PCB	1	<input type="checkbox"/>
5	PA050XS1	5"TFT	1	<input type="checkbox"/>
6	GBIP3.848.074	speakers set	1	
7	GBIP8.075.013	display panel	1	
8	GBIP8.080.042	disc cover	1	
9	GBIP8.912.040	bolt□ST1.8×5.2□	14	
10	GBIP8.639.088	protective pad	3	
11	GBIP8.668.011		1	
12	GBIP8.074.030	top cover	1	
13	GBIP6.309.003	running shaft set	1	
14	818M2X5	bolt	4	
15	GBIP8.047.003	running shaft cover	1	
16	GBIP8.073.073	holder of cover	2	
17	GBIP8.912.041	bolt□ST1.8×4.5□	3	
18	GBIP8.337.466	switch of disc cover	1	
19	GBIP8.387.020	spring of disc cover	1	
20	GBIP6.644.001	tabular cable	1	
21	GBIP8.639.121	pad of shock absorption	3	
22	DCH-5A	battery spring	1	
23	S16□□	DVD loader	1	<input type="checkbox"/>
24	GBIP8.914.045	bolt□ST1.8×4.3□	2	
25	GBIP8.034.184	metal soleplate	1	
26	GBIP8.047.004	metal connectors	1	
27	GBIP8.912.039	bolt□ST2×12□	7	
28	GBIP8.639.2000	feet pad	4	
29	GBIP8.074.031	bottom base	1	
30	GBIP8.337.345	key 2	1	
31	GBIP2.855.583MX	main PCB	1	<input type="checkbox"/>
32	GBIP8.337.469	key(five pieces)	1	
33	GBIP8.640.095	mantle of remote control	1	
34	GBIP8.640.094	indicator light	1	
35	GBIP8.337.468	cable clamp	1	
36	GBIP8.640.093	transparent quoit	1	
37	GBIP8.382.110	columnar spring	1	
38	GBIP4.021.241	keystoke board set	1	
39	GBIP8.337.472	rocker key	1	
40	GBIP8.079.008	pushing pole	1	
41	GBIP8.337.467	switch of disc cover	1	
42	GBIP8.387.021	spring of disc cover	1	