

Telephone:
 Fax:
 UST-IdNr.:

Y11	AC compressor clutch
A63	AC control module
B53	AC evaporator temperature sensor
S369	AC refrigerant quadruple pressure switch
M112	AC/heater air direction motor
M104	AC/heater air intake flap motor
M114	AC/heater air mix flap motor
A176	AC/heater blower control module
M7	AC/heater blower motor
S292	AC/heater function control panel
31	Battery -
30	Battery +
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A35	Engine control module (ECM)
M6	Engine coolant blower motor
A95	Engine coolant blower motor control module
K12	Engine coolant blower motor relay
R46	Engine coolant blower motor resistor
B24	Engine coolant temperature (ECT) sensor
S186	Engine coolant temperature (ECT) switch
F	Fuse
X28-II	Fuse box/relay plate - engine bay
X28-I	Fuse box/relay plate - fascia
B162	Heater radiator temperature sensor
15	Ignition switch - ignition ON
B37	In-car temperature sensor
M51	In-car temperature sensor blower
A11	Multifunction control module
B61	Outside air temperature sensor
A171	Relay module
B33	Vehicle speed sensor (VSS)

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

