


— : +B line - - - - - : -B line

B MAIN CIRCUIT
(P.C.BOARD ON PAGE 27)



E TO SENSOR CIRCUIT (CN501) (PAGE 26)

H TO LOADING MOTOR CIRCUIT (CN531) (PAGE 26)

C TO PANEL CIRCUIT (CN601) (PAGE 26)

C TO PANEL CIRCUIT (CN602) (PAGE 26)