

42 button

URC22B V.1

0Ch TV1 TV2 AUX

SET VCR1 VCR2 CBL SAT

01h
02h
03h
04h
3Fh

05h
06h
07h
08h
3Ah

09h
0Ah
0Bh
2Bh
2Bh

29h 3Bh - 1Ah

0Eh 1Ch - 1Bh

0Dh
11h
10h
25h

addr: 10h

x	
x	
1	Start1
1	Start2
0/1	Togle
1	ADD1
0	ADD2
1	ADD3
0	ADD4
0	ADD5
0/1	Comm1
0/1	Comm2
0/1	Comm3
0/1	Comm4
0/1	Comm5
0/1	Comm6

address: 0x14

14 bit

KOD: 0552

Address: 14h