

42 button

URC22B V.1

0Ch TV1 TV2 AUX

SET VCR1 VCR2 CBL SAT

01h

02h

03h

04h

05h

06h

07h

08h

09h

0Ah

0Bh

0Ch

0Dh

0Eh

0Fh

0Bh

1Dh

27h

0Fh 3Fh 12h 14h

31h 2Bh 13h 15h

0Eh 2Fh 3Fh 3Ch

37h 2Dh 2Ah 0Dh

0Dh

addr: 14h

x		address: 0x05	14 bit
x			
1	Start1	command	
1	Start2		
0/1	Togle		
0	ADD1	command	
0	ADD2		
1	ADD3		
0	ADD4		
1	ADD5		
0/1	Comm1	command	
0/1	Comm2		
0/1	Comm3		
0/1	Comm4		
0/1	Comm5		
0/1	Comm6		

KOD: 0278
Address: 05h