SOUND PROCESSOR

I302

TDA9870A/75A

TUNER

TU01

AUDIO AMPLIFIER

IA01 TDA2615 (TDA2616)

RESET

EEPROM

IC02

24C16

uCONTROLLER+VIDEO PROCESSOR

TDA9350/52/53/55/57/59/60/61/62/63/64/65/66/67/68/69/70/71/72/73/74/75/76/77/78/79/80/81/82/83/84/85/86/87/88/89/90/91/92/93/94/95/96/97/98/99/8X

IV01

DOLBY AMPLIFIER

IA51 TDA7057AQ

MONO/OPT.

IA50 TDA7056A

SERVICE

INFRARED MODULE

SECAM L MONO SOCKET

DOLBY SOCKET

HEADPHONE AMPLIFIER

TDA7050

IH01

CRT BOARD 99TA001

I001 TDA6107Q

SCARTS

SCART20´21 KE02

SCART20´21 KE01

VIDEO SWITCH

E/W DRIVE

VERTICAL

TDA8356 (TDA8351)

IC04

115V +B (145V +B) POWER SUPPLY

IP01 TDA16846

IP02 LE33AB/C

IP04 LM7805

IP03

HORIZONTAL

WD02

FBT

⚠INDICATES SPECIALLY SELECTED OR CRITICAL SAFETY COMPONENTS AND IDENTICAL COMPONENTS SHOULD BE USED FOR THERE REPLACEMENT. THIS IS NECESSARY IN ORDER TO MAINTAIN THE OPERATIONAL SAFETY OF THE RECEIVER.

THE SERVICE INFORMATION FOR SAFETY

WHEN SERVICING THIS AREA CONNECT AN ISOLATING TRANSFORMER BETWEEN TV RECEIVER AND AC LINE TO ELIMINATE HAZARD OF ELECTRIC SHOCK.

PT92 WEBTV CHASSIS SCH.DIAGRAM | VER.E