

S1 a ~ b SELECTOR
1 PHONO
2 TUNER
3 AUX

S2 a ~ b TAPE MONITOR 1
1 SOURCE
2 MON. 1

S3 a ~ b TAPE MONITOR 2
1 SOURCE
2 MON. 2

S4 a ~ b LOUDNESS
1 OFF
2 ON

S5 a ~ b HIGH FILTER
1 OFF
2 ON

S6 a ~ b SPEAKER
1 OFF
2 A
3 B
4 A+B

(v): DC VOLT AT NO INPUT SIGNAL.

[V]: DC VOLT AT 35W x 2 (8OHM·1KHz)

LL DIAGRAM **TRM-650**



BLOCK DIAGRAM



= ONE CHANNEL ONLY =

GRAM **TRM-650**


TAPE MON-1 SWITCH
TAPE MON-2 SWITCH
VOLUME CONTROL
TONE AMP
BALANCE CONTROL
TONE AMP
BASS CONTROL
TREBLE CONTROL
LOUDNESS SWITCH
HI-FILTER SWITCH
PROTECTOR AMP
SPEAKERS SWITCH
OUT PUT Ⓐ
OUT PUT Ⓑ
HEAD PHONE