Component Placing, Electrical

Applicable for K320 and W200i

Contents

1 Mounting drawing table 2
2 Mounting drawing ODM900-50201153 3
3 Mounting drawing ODM650-50162550 6
4 Mounting drawing W200i, HW3101 (900MHz) 8
5 Mounting drawing W200i, HW3151 (850MHz) 11
6 Mounting drawing W200i Keyboard 20 14
7 Revision history 16

© Sony Ericsson Mobile Communications AB

1 Mounting drawing table

Board Number	Drawing	Comments
ODM900-50201153 (K320)	E3002_006_asmb_value_testpoints 01mar_2006.pdf	Main board
ODM650-50162550 (K320)	28_asmb_29dec2005.pdf	UI Board
Melinda HW3101 (W200i, 900MHz)	Melinda_Engine_3101_asmb_value _testp_05dec2006.pdf	Main Board
Melinda HW3151 (W200i, 850MHz)	Melinda_Engine_3151_asmb_value _testp_05dec2006.pdf	Main Board
Melinda Keyboard 20	Melinda_Keyboard_2001_asmb_va lue_28aug2006.pdf	UI-Board

By using the “Search” function and enter the component name you can find the position of the component.
You can see the component name “highlighted” on the circuit board (use zoom to enlarge).







© Sony Ericsson Mobile Communications AB

2 Mounting drawing ODM900-50201153

© Sony Ericsson Mobile Communications AB


N1
X600
X601
X1
X2
D400
S902
S901
S903
D800
D500
D300
D303
L601
G400
SC300
D802
S701
V901
V905
V904
V903
V902
V601
V602
V603
V604
V612
C527
C528
C909
R615
L603
L604
C704
C705
C635
C636
C546
L507
L508
C545
C547
C312
R906
C604
C602
R614
C605
C606
C601
R831
CM605
C608
C607
C609
R604
C610
R605
CM606
L602
V611
R603
R604
CM4
C634
R827
V606
CM604
R838
C627
CM602
CM601
C633
C611
C628
C613
C622
C621
C626
C615
R819
C410
C614
R606
V608
R817
R822
R823
R820
R821
R815
R501
C603
C513
R603
C632
C616
C617
C506
C507
R607
C618
CM600
CM603
C630
C612
C629
C619
C620
C414
C432
C416
R611
R602
R833
R832
R601
R406
R403
R402
R400
C400
C401
V900
R312
V908
R1
R8
C985
R828
L2
C7
C5
C6
C421
CM41
R405
C445
R404
C424
R831
R435
C417
R830
R433
R415
R414
R412
R818
R701
R714
R712
R703
R715
C426
R704
R702
C869
C871
C838
L800
C701
R705
C551
CM315
R706
R710
V702
V301
C870
C301
C304
C300
R711
R709
V701
C422
C306
R319
R320
D302
C412
C428
C413
D301
R318
C303
C302
C430
R609
C427
R411
C405
C425
R608
C409
R311
C431
C418
C423
C411
C429
R313
R830
R829
D803
R836
R824
R513
C537
R516
R506
R837
V502
V501
R826
R825
R515
V599
N500
C542
C544
C516
R518
C539
C557
C550
C540
C541
R514
C548
C549
C514
C524
C525
C526
C532
C531
L501
C509
C515
R537
L500
C508
C523
R507
C505
L504
C855
C853
C877
C878
R608
R607
C914
C913



1078-2/FEA 209 544/124 B

B-SIDE

3 Mounting drawing ODM650-50162550

© Sony Ericsson Mobile Communications AB

ODM650-50162550



4 Mounting drawing W200i, HW3101 (900MHz)

© Sony Ericsson Mobile Communications AB


S902
C912
R906
D400
X2
X1
R2
R3
L5
C546
L507
L508
C545
C547
N1
V901
V905
V904
V903
C604
C602
R614
C605
C606
C601
R831
X600
V601
V602
C527
C528
C909
V603
V604
C635
C636
L603
V612
L604
C704
C705
SC300
X601
C608
C607
C609
R604
C610
R605
V611
R604
CM4
CM606
L602
V606
CM604
R838
C627
C622
C621
C626
R610
V608
C615
C633
CM602
CM601
C634
R827
C611
C628
C637
C638
R819
C613
C410
C614
V906
C617
C506
C507
R607
C618
C630
C612
C629
C505
C504
C531
L509
L504
R817
R822
R823
R820
R821
R815
R501
C603
C513
R603
C632
R836
R826
R825
L505
V502
N500
V503
V501
C544
C517
R514
C516
C559
C560
C548
C549
C514
C524
C525
C526
C532
R517
R513
C537
R516
R515
V999
C542
L506
C540
C541
L501
C509
C515
L500
C508
C523
R824
R830
R313
R829
D803
C551
R837
R836
V300
R312
C605
R628
C5
L2
C7
C6
R833
R832
V902
R602
R601
R406
R403
R402
C401
C400
G400
C616
R607
C407
CM600
CM603
R611
C414
C432
C416
C619
C620
V908
R1
R8
C421
C4417
R405
R401
C415
C402
C404
C940
R424
R713
R301
R416
R417
R300
R413
R414
R415
R412
R712
R715
C426
R818
R701
R714
S701
R703
R702
R704
C424
C310
C871
C869
C858
L601
D802
C308
R615
R710
R706
R705
C701
V607
V702
C304
V301
C870
R711
R709
V701
C422
C306
R319
D302
R320
C412
C428
D301
C413
R318
R323
R315
R314
R316
C309
C302
C300
C301
C303
D500
D300
D303
C430
R303
R609
R305
R427
R411
C405
C425
R608
C409
R311
C431
C418
C423
C411
C429
D800
S901
S903
S904
R909
C855
C917
C915
C877
C878
C853
R907
R908
C913
C914


V613
C911
R905
R900
C510
C511
L502
L503
C512
C404
R409
R408
R407
CM400
C403
R410
S900
X800
V610
C623
C625
R903
R904
C103
N601
C101
CM01
N101
R106
C121
C120
R108
R103
R104
C102
C624
C109
C108
C536
R101
R509
C534
D101
R321
R322
R317
C313
C132
C123
L103
R107
R102
R302
N200
C305
R610
C533
C111
C112
C110
C106
C307
C335
R608
C115
L102
L101
C114
C113
CM300
C311
R901
R900
C876
SC100
V704
C864
R902
V907
C631
C703
Z701
R707
C702
L704
L701
L703
L702
L706
L705
V609
R606
R708
V705
D501
C518
C519
C705
C707
R512
C522
C521
C504
X300
X900
C916
R910
C910

5 Mounting drawing W200i, HW3151 (850MHz)

© Sony Ericsson Mobile Communications AB


S902
R906
C912
D400
X2
X1
C9
R3
C546
L507
L508
C545
C547
N1
V901
V905
V904
V903
C604
C602
R614
C605
C606
C601
R831
X600
V601
V602
C527
C528
C909
V603
V604
C635
C636
L603
V612
L604
C704
C705
SC300
X601
C608
C607
R604
C610
R605
V611
R654
R653
CM4
CM606
L602
C609
V606
CM604
R838
C627
CM602
CM601
C634
R827
C637
C638
R819
C633
C611
C628
C613
C622
C621
C626
C615
L601
R610
V608
R817
R822
R823
R820
R821
R815
R501
C603
C513
R603
C632
D500
V900
R312
V908
R1
R8
C865
R828
C5
L2
C7
CM417
R401
C402
C540
R713
R416
R300
R414
R412
R818
R701
R714
C869
C6
C421
R405
C415
R404
C424
R301
C417
R413
R415
R712
S701
R703
R702
R715
C426
R704
R833
R832
V902
R602
R601
R406
R403
C410
C614
C617
C506
C507
C616
R607
C618
C407
CM600
R611
C414
C432
C416
C619
C620
C612
C629
C630
CM603
V909
R402
C401
C400
G400
D300
D802
C868
C871
C838
L800
C310
C870
R711
R709
V702
V607
R615
R710
R706
R705
C701
C304
V301
V701
C422
C306
R319
D302
R320
C412
C428
D301
C413
R318
R323
R315
R314
R316
C309
C302
C300
C301
C303
D303
S901
S903
S904
D800
R909
C855
C915
C877
C878
C853
C917
R907
R908
C913
C914
D803
R830
R313
R829
R824
R513
C537
C551
R837
R516
R506
R515
V599
C542
V503
V502
N500
R836
V501
R826
R825
L505
C540
C541
R514
C539
C544
C517
C516
C560
R518
C548
C549
C514
C524
C525
C526
C532
C531
C505
L504
L501
C509
C515
R517
L509
L500
C508
C523


V613
C911
R605
R550
C510
C511
L502
L503
C512
C404
R409
R408
R407
CM400
C403
R410
S900
X800
V610
C623
C625
R903
R904
C103
N601
CM101
N101
C101
C120
R108
R103
R104
C102
C121
R106
C624
C538
R609
C534
C122
D101
R321
R322
R317
C313
C123
C535
R608
C533
C111
C112
L102
L101
C114
C108
C113
R107
L103
C109
R101
R102
C110
C115
C307
C311
CM300
N300
C305
R302
R901
R900
C876
SC100
C864
R902
V907
C631
V704
C703
Z701
R707
C702
L704
L701
L703
L702
L706
L705
V705
R606
R708
V609
D501
C518
C706
C707
C519
C522
C521
C504
R512
X300
X900
C916
R910
C910

6 Mounting drawing W200i Keyboard 20

© Sony Ericsson Mobile Communications AB


V1008
V1002
R1002
R1001
V1001
V1004
R1004
V1003
R1003
V1006
R1006
V1005
R1005
V1007

7 Revision history

ev.	ate	Changes / Comments
A	2006-10-16	First draft.
B	2006-12-22	W200i phone added.

© Sony Ericsson Mobile Communications AB