


SCHEMATIC DIAGRAM HE, HB models



1. RESISTORS:
 Indicated in Ω, NW, 10% tolerance unless otherwise noted; k: KΩ, M: MΩ, (F): 1%, (G): 2%, (K): 10% tolerance.

2. CAPACITORS:
 Indicated in capacity (μF) (voltage (V)) unless otherwise noted; p: pF. Indication without voltage is 50V except electrolytic capacitor.

3. VOLTAGE, CURRENT:
 □: Signal voltage at 20W + 20W 8Ω output (1kHz)
 □: DC voltage (V) at no input signal
 □: Value in 1/8 DC voltage at rated power.
 ←mA: DC current at no input signal

4. OTHERS:
 ⊙: Adjusting point
 The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.

This is the basic schematic diagram, but the actual circuit may vary due to improvements in design.

SWITCHES:
 S1: FUNCTION TUNER- PHONO - AUX
 S2-1, 2 TAPE MONITOR ON - OFF
 S2-3, 4 LOUDNESS ON - OFF
 S3-1, 2 SPEAKER A ON - OFF
 S3-3, 4 SPEAKER B ON - OFF
 S5: POWER ON - OFF

The underlined indicates the switch position.

D1 1S1554
 D3 MZ-197
 D5 MZ-157